




Parker QuickFit[™] Oil Change System



Parker Hannifin's QuickFit Oil Change System revolutionizes the process with a faster, cleaner and safer way to change engine oil. In three easy steps, purge, extract and refill your system with new oil without ever spilling a drop. QuickFit helps you simplify your routine maintenance, increase productivity and virtually eliminate the risk of spills and contamination.

Industries

- Heavy Machinery
- Fleet / Trucking
- Municipalities
- OEMS

- Transportation
- Power Generation
- Rental Companies
- Waste Management

Exotic Automation & Supply is a Factory Authorized Installer & Trainer!

Why QuickFit System?

Faster.

15

Minutes or Less to change oil with the QuickFit System.

Safer.

75%

Improvement in safety conditions for oil changes.

Cleaner.

100%

Elimination of oil spills, leaks and drips.

Phone: (248) 477-2122 • Email: sales@erpc.com • www.exoticautomation.com



Components:

The QuickFit Oil Change System has everything you need:

- Parker QuickFit Valve
- Parker Push-Lok Hose
- Parker Adapters/Fittings
- Parker QuickFit Bracket
- Equipment specific Installation Guide, complete with images and detailed instructions

Three Simple Steps


1 Purge Filter

- Attach compressed air supply to Filter Purge Tool (FPT)
- Connect FPT to QuickFit Valve
- Hold lever on FPV for 10 seconds
- Disconnect FPT

AIR SUPPLY (PRESSURE)


(2) Evac Oil

- Connect waste oil suction hose to QuickFit Valve
- Turn on waste oil pump
- Replace oil filter while the pump is removing the oil from the sump
- Disconnect when oil is removed



3 Refill Oil

- Connect clean oil hose
- Turn on oil pump to refill clean oil through new filter
- Disconnect clean oil line when refilled to capacity





Watch the video to see how the QuickFit Oil Change System is a cleaner, faster and safer alternative to a traditional oil change.